


Part List for CCP-380R Tool



Part No.	Part Name	Q'ty	Part No.	Part Name	Q'ty
1	Cylinder CAP	1	36	ORING	1
2	RUBBER BOTTOM	1	37	NOSEPIECE (1/4")Ø6.4	1
3	AIR CYLINDER BODY	1	37-1	NOSEPIECE(7/32")Ø5.6	1
4	ORING	1	37-2	NOSEPIECE(3/16")Ø4.8	1
5	NUT	1	37-3	NOSEPIECE(5/16")Ø7.8	1
6	WASH	1	38	FRAME HEAD	1
7	AIR PISTON	1	39	JAW HOUSING	1
8	ORING	1	40	JAW	3
9	ORING	2	41	JAW PUSHER for 5/16"(max mandrel diameter 4.5mm)	1
10	ORING	1	41A	JAW PUSHER for 1/4"-3/16"	1
11	Crash Washer	1	42	JAW HOUSING COUPLER	1
12	ORING	1	43	SPRING	1
12-1	ORING	2	43-1	SPRING COLLAR	1
13	TUBE	1	44	ORING	2
14	ROD	1	45	CASE WASHER	1
15	STEM NUT	1	46	CASE LOCK NUT	1
16	SEAL	1	47	SEAL	1
17	ORING	1	48	ORING	1
18	WEAR RING	1	49	OIL SEAL WASHER	1
19	STEM	1	50	HEXAGON SOCKET SCREW	1
20	MUFFLER	1	51	HOOK	1
21	ORING	2	53	OIL CYLINDER BODY	1
22	ORING	3	54	PISTON ROD II	1
23	CAGE	1	55	BACK-UP RING	1
24	ORING	1	56	SPRING	1
25	VALVE	1	57	ORING	1
26	VALVE CAP	1	58	FRAME CAP NUT	1
27	RETAINING RING	1	59	SPENT MANDREL BOTTLE	1
28	VALVE PISTON	1	60	ORING	1
29	HANDLE BODY	1	61	MANDREL BOTTLE ADAPTER	1
30	ORING	1	61-1	SILENCER	1
31	TIGGER INSERT	1	62	SPANNER	1
32	TIGGER HEAD	1	63	SPANNER GAUGE	1
33	TRIGGER	1	64	OIL CAN	1
34	SPRING PIN	1	65	SHOUTOFF VALVE	1
35	ORING	1	67	ORING	5
			68	CUSHION	1

Fig. 5 of CCP-380R Tool.