


11. EXPLODED DIAGRAM : FS-100C

WARNING

This diagram is for your reference only. Do not attempt to service or repair the Tool. Do not take the Tool apart. Contact an authorized Nitto dealer for all service and repair of the Tool. Improper service and repair can cause accidents and service injuries. Never attempt to modify the Tool. Never attempt service or repair the Tool yourself.



The part numbers with () are included in the Ass'y parts written above them.

| No. | Part No. | Description | Qty | Price |
|-----|-----------|--|------|-------|
| 29 | TB08683 | Housing Cover Ass'y | 1set | |
| 1 | (TP15371) | Housing Cover | 1 | |
| 27 | (TP04218) | Label NITTO | 1 | |
| 28 | (TQ12752) | Warning Label CE Mark | 1 | |
| 2 | TP15374 | Trigger | 1 | |
| 3 | TA99365 | Housing Sub Ass'y | 1set | |
| 4 | TP04234 | Spring Lock Washer M4 | 4 | |
| 5 | TPI 4488 | Cross Recessed Pan Head Tapping screw 4 x 20 | 4 | |
| 6 | TP15376 | Spring 0.45 x 3.1 x 17 | 1 | |
| 7 | TPI 5375 | Cancel Switch | 1 | |
| 8 | TA91647 | Tube Ass'y | 1set | |
| 26 | TA99971 | CLamp Ass'y | 2set | |
| 9 | (TP10870) | Clamp Spring | 2 | |
| 10 | (TP11245) | Cross Recessed Pan Head Screw 4x10 | 8 | |
| 11 | (TP10872) | Clamp Stopper B | 2 | |
| 12 | (TP17901) | Clamp Stopper C | 4 | |
| 13 | (TP10871) | Clamp Stopper A | 2 | |
| 14 | TA9A372 | Base Plate Sub Ass'y | 1set | |
| 16 | TA99364 | Throttle Valve Ass'y | 1set | |

| No. | Part No. | Description | Qty | Price |
|-----|----------|---|------|-------|
| 17 | TA91575 | Cross Recessed Pan Head Screw 4 x 8 Ass'y | 1set | |
| 19 | TP16951 | Filter | 1 | |
| 20 | TA96330 | Rubber Support Ass'y | 4set | |
| 21 | TA9A369 | Turbine Ass'y | 1set | |
| 22 | TP03790 | O Ring S-56 | 1 | |
| 23 | TA9A371 | End Cap Ass'y | 1set | |
| 24 | TP01945 | Hex. Socket Head Cap Screw 5 x 12 | 1 | |
| 25 | TA9A367 | Rubber Pad Ass'y | 1set | |

ACCESSORIES

| No. | Part No. | Description | Qty | Price |
|-----|----------|---------------------------|------|-------|
| 15 | TB08077 | Air Hose H Ass'y | 1set | |
| | TP02236 | Bushing R 1/4 x NPT 1/4 | 1 | |
| | | Abrasive paper # 180 | 5 | |
| | | Abrasive paper # 240 | 5 | |
| | TQ12753 | Instruction Manual | 1 | |
| | TQ12754 | Declaration of Conformity | 1 | |